

AIRDOPES PRIME 513 ANC SMART GUIDE

CONTENTS

PACKAGE














(8)





(q)

(*)

(Pm)

(2X/00)


(Pm)

Long Touch (3s) Left Earbud Right Earbud Tap 3 Times

Long Touch (3s) Long Touch (5s)








BLUETOOTH

PAIRING



<u>√x | ~ | √</u>



(VOICE ASSISTANT / BEAST™ MODE)

Toggle Noise Cancellation Modes

Touch Control Customization

RESET AIRDOPES

RESS RESET BUTTON FOR 10 SECONDS

Smart Diagnostics Mode Connectivity and Battery Status

Activate/Deactivate Multipoint Connectivity

EQ Customization



Note: Red LED blinks 5 times rapi


LED STATUS GUIDE

LED STATUS GUIDE

CASE LED INDICATION

BLUE LED BLINKS 1 TIME WHEN LEFT EARBUD IS CHARGING BLUE LED BLINKS 2 TIMES WHEN RIGHT EARBUD IS CHARGING BLUE LED BLINKS 4 TIMES WHEN BOTH EARBUDS ARE CHARGING

100% : BLUE LED BLINKS 4 TIMES WHEN BOTH EARBUDS ARE FULLY CHARGED



EARBUD STATUS

FULLY CHARGED

Up to 32 dB ANC Up to 65 hrs total playtime (Non-ANC Mode);

Note: - In case the earbuds battery level drops below 20%, the earbuds will play a tone promp to indicate low battery status.

When the earbuds are inside the charging case, the case LED shows the battery level of the earbuds. Once the earbuds are removed from the charging case, the case LED shows the batt level of the charging case.




e earbuds will play a tone prompt

(*****

 \odot

CLOSE THE LID AND WAIT FOR 5 SECOND OPEN CASE & PERFORM A FRESH CONNECTION.

Up to 40 hrs total playtime (ANC Mode s : 4



Note: (1) Before using the earbuds for the first time, it is reconcharge them.
(2) Please note that the earbuds cannot be used / switched or

SPECIFICATIONS

Headphone Type Bluetooth Version Noise Cancellation

Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.

4