





ROCKERZ 421 GEN 2

SMART GUIDE


PACKAGE CONTENTS




PRODUCT LABELLING




POWER ON/OFF



BLUETOOTH PAIRING



DUAL PAIRING



Note: If the headphones are not connected, try connecting the first device manually once again to activate dual pairing.




FUNCTIONS (CALL/MUSIC/VOLUME)



Note: The headphones may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the headphones.



FUNCTIONS (BEAST™ MODE / VOICE ASSISTANT)



BEAST™ Mode: Short press the BEAST™ Mode Quick Switch button to activate BEAST™ Mode for low-latency gaming. Short press the BEAST™ Mode Quick Switch button again to switch to boAt Signature Sound.


Voice Assistant: Double press the MFB to activate the default smart voice assistant (Google Voice Assistant/Siri).

Note: boAt Signature Sound remains on by default. If the voice assistant doesn't get triggered, then the functionality has to be first enabled via your media device settings.

The headphones may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the headphones



RESET ROCKERZ




Congratulations! Your Rockerz 421 Gen 2 has been reset.

Note: Purple LED flashes 3 times on the headphones to indicate successful reset



LED STATUS GUIDE



SPECIFICATIONS

Headphone Type	Bluetooth Headphones
Driver Size	50 mm*2
HD Sound	Yes
THD	≤3% @1kHz
Bluetooth Version	5.4
Bluetooth Profiles	A2DP,AVRCP,HFP,HID,AVCTP,AVDTP,SPP
Music Playtime	Up to 60 hours (at 60% volume)
Standby Time	>300 hours
ENx™ Tech	Yes
Mic Sensitivity	-42dB
BEAST™ Mode	Yes
Transmission Range	10 m
Signal-to-Noise Ratio	≥90dB
Frequency	20 Hz-20 kHz
Battery	600 mAh
Charging Time	Up to 4 hours
Charging Interface	USB Type-C
Charging Voltage	5V
Water Resistance	IPX4

CHARGING GUIDELINES

Note: (1) Before using the headphones for the first time, it is recommended to fully charge them.

(2) Please note that the headphones cannot be used / switched on while charging.

LEARN MORE ABOUT YOUR PRODUCT

Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information