



AIRDOPES 71 GEN 2

SMART GUIDE


PACKAGE CONTENTS





PRODUCT LABELLING




SMART POWER ON/OFF



MANUAL POWER ON/OFF




Press and hold each earbud CTC for 3 seconds and release



Press and hold each earbud CTC for 10 seconds and release


BLUETOOTH PAIRING



FUNCTIONS (CALL/MUSIC)




TOUCH FUNCTIONS



Note: The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

FUNCTIONS (VOICE ASSISTANT/ BEAST™ MODE)



ACTIVATE GOOGLE VOICE ASSISTANT/SIRI



ACTIVATE/ DEACTIVATE GAMING BEAST™ MODE

Voice Assistant: Long press the CTC on the left earbud for 2 seconds to activate the default smart voice assistant (Google Voice Assistant/Siri).
BEAST™ Mode: Long press the CTC on the right earbud for 2 seconds to activate BEAST™ mode. Long press the CTC on the right earbud for 2 seconds again to de-activate BEAST™ mode.

Note:
• boAt Signature Sound remains ON by default.
• If the voice assistant doesn't get triggered, then the functionality has to be first enabled by your media device settings.
• The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on the media device.

HEARABLES APP COMPATIBILITY

Discover the following features of your Airdopes only on the Hearables App:

- ✓ Volume Control
- ✓ Music & Audio Book Streaming
- ✓ Ring My Buds
- ✓ Connectivity Status
- ✓ User Manual



RESET AIRDOPES

Congratulations! Your Airdopes 71 Gen 2 has been reset.
Note: Red LED blinks 5 times on both earbuds to indicate successful reset.

LED STATUS GUIDE

LOW BATTERY (<25 %): LEFT LED REMAINS SOLID ON	LOW BATTERY
CHARGING: LED BLINKS 1 TIME EVERY SECOND	CHARGING
FULLY CHARGED (100%): ALL LEDs REMAIN SOLID ON	FULLY CHARGED

<20%: RED LED BLINKS 3 TIMES WITH TONE PROMPT	LOW BATTERY
SOLID RED LED	CHARGING
100%: RED LED TURNS OFF	FULLY CHARGED

SPECIFICATIONS

Headphone Type	TWS Earbuds
Bluetooth Version	6.0
Music Playtime (with Charging Case)	Up to 45 hrs (at 60% volume)
Number of ENx™ Equipped Mics	2
IWP™ Tech	Yes
BEAST™ Mode	Yes; 45 ms Low Latency
Transmission Range	10 m
Driver Size	10 mm*2
Supported Codecs	AAC/SBC
Frequency	20 Hz-20 kHz
Battery	400 mAh (Case); 40 mAh*2(Earbuds)
ASAP™ Charge	Yes; 10 mins charge = 150 mins playtime
Charging Time	30 mins (Earbuds); 90 mins (Case)
Charging Interface	USB Type-C
Water Resistance	IPX4

CHARGING GUIDELINES

Charging norms & Precautionary Guidelines: -	
1) Charger/Brick/Adapter	5V/2A
2) Cable/Wire	Standard Cable (35 strands @0.10mm diameter/ strand)
Any other accessory can be used to charge the product as long as the above-mentioned norms are followed.	

Note: (1) Before using the earbuds for the first time, it is recommended to fully charge them. (2) Please note that the earbuds cannot be used / switched on while charging.

WEEE INFORMATION

This device and any electrical accessories are compliant with local applicable rules on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Disclaimer: Features may vary by product model. For detailed specifications, please refer to the product user guide. Due to ongoing improvements, specifications are subject to change without prior notice. We continuously enhance our products to ensure the highest quality.

LEARN MORE ABOUT YOUR PRODUCT

Scan this QR Code to Access Your Product's Manual, FAQs, and Warranty Information