



AIRDOPES JOY V2

Get ready to immerse yourself in musical bliss with your very own pair of boAt Airdopes Joy V2. Please consider this manual as your guiding map towards the unparalleled shores of auditory realm. Knowledge of Bluetooth and device connectivity is essential for steering this boat and therefore we strongly recommend thorough reading of this manual. Also, you may refer to the same at times when you face any sort of difficulty.



USER MANUAL

CHARGING THE EARBUDS

Step 1: Please insert the earbuds back inside the charging case in correct orientation and close the lid

Step 2: In charging status, the red LED Solid turns on when case lid gets opened. LED stays off when the lid stays closed.

Step 3: Once the earbuds get fully charged, the charging case automatically switches off to save power, and the red LED stays turned off.

Note
• Before using the earbuds for the first time, it is recommended to fully charge the earbuds. Also, please keep the lid of the charging case closed while charging.

• To indicate low earbud battery, red LED blinks thrice every 30 seconds

CHARGING THE CASE

Step: To charge the case, plug one end of the provided cable into the case and connect the other end to a computer/ wall adapter/ powerbank, etc.

Charging norms & Precautionary Guidelines: -	
1) Charger/Brick/Adapter 2) Cable/Wire	: 5V/2A : Standard Cable (35 strands @0.10mm diameter/ strand)
Any other accessory can be paired up with the product as long as the specifications are as per above norms.	

REMAINING CASE BATTERY LED INDICATIONS

Scenario	Indication
Less than 20% battery	WHITE LED blinks continuously when the Case lid is opened/Closed
More than 20% battery	WHITE LED is solid on for 8 seconds when the Case lid is opened/closed
Case in charging mode	WHITE LED continuously blinks
Case fully charged	WHITE LED is solid on

CASE RED INDICATION WHEN EARBUDS ARE GETTING CHARGED FROM THE CASE

This is to indicate the earbud getting charged from the case (when case lid gets closed):
• WHITE LED is Solid ON for 8 seconds while charging
• WHITE LED is OFF when Earbuds are charged fully

BASIC FUNCTIONS


- Voice Assistant: Triple tap on left CTC to activate default smart voice assistant
- Answer: Single tap the CTC on either earbud to answer an incoming call

PACKAGE CONTENTS

- 1 UNIT boAt Airdopes Joy V2

OVERVIEW

- 1 CTC (Capacitive Touch Control) / Power Button



POWER ON (FIRST TIME USER):

Step 1: To switch the earbuds on (Smart Power On) simply open the lid of the charging case (when earbuds are inside). Courtesy our IWP™ (Insta Wake N' Pair) technology, the earbuds power on automatically, get connected and enter the connection mode

OR

Long touch the CTC (Capacitive Touch Control) on both earbuds for 3 seconds to manually power on the earbuds



Step 2: After powering on, the earbuds enter the Connection Mode, indicated by alternate red and blue LED flashes on primary earbud and blue LED flashes once every 5 seconds on the secondary earbud

ENx™ TECH

Our ENx™ tech algorithm cancels out the background noise so that you can be heard crystal clear via voice calls. One need not activate ENx™ as the mics are equipped with the same and activated by default.

Deliver your voice without interruptions anywhere – traffic, railway stations, airports, work space; literally anywhere!

SMART POWER OFF

Step 1: After usage, remove both the earbuds from your ears

Step 2: Place the earbuds back into the charging case in correct orientation and close the lid

The earbuds automatically switch off (and enter charging mode).

MANUAL POWER OFF

Step 1: Long touch either CTC for 8 seconds to manually power off the earbuds

Step 2: Once the earbuds get turned off, place them back inside the case and close the lid

CONNECTION MODE:

Step 3: Turn on the Bluetooth functionality on your phone/media device and scan.

Step 4: Search for 'Airdopes Joy V2' and pair accordingly.

Congratulations! Your earbuds are connected successfully via Bluetooth

Note :

- Pairing Mode: It lasts for 5 minutes. If the pairing time is missed then you will need to reconnect the earbuds and follow the above-mentioned procedure
- Airdopes Joy V2 remembers previously connected devices; once switched on, the earbuds automatically reconnect to the previously connected devices in working range.



BEAST™ MODE

Triple tap the right CTC to switch to Low Latency mode, also known as the BEAST™ Mode. Once switched on, it gets notified via a sound prompt. Triple tap the right CTC once again, to turn it off and return to standard Music Mode.

Made for the Gamers - By Gamers, BEAST™ Mode reduces the latency significantly and improves the overall gaming experience.

FACTORY RESET

Perform the factory reset in case you feel any difficulty while operating your Airdopes.

*NOTE: Before performing reset, clear "Airdopes Joy V2" from pairing device history by forgetting device

Step 1: Take out the earbuds from the charging case, and long touch the CTC for 5 seconds on both the earbuds.

Step 2: Place the earbuds inside the Case.

Step 3: Close the lid, wait for 5 seconds.

Step 4: Take out the earbuds from the charging case and perform a fresh connection.

Note: To complete the factory reset, all of the above steps should be performed.

Congratulations! Your Airdopes Joy V2 has been Reset

SINGLE EARBUD USAGE

Step 1: Please note that both the earbuds can be used in mono mode. Use Smart / Manual Power On for switching on the desired earbud

Step 2: The Selected earbud automatically enters the connection mode indicated by rapid red & blue LED flashes.

Step 3: Turn on Bluetooth on your phone/media device and search for 'Airdopes Joy V2' to connect

Notes:

- To switch to Stereo mode, simply take out the other earbud from the case. It will automatically power on and pair with the previously selected earbud, hence enabling Stereo usage
- You can only skip to the next track while using the right earbud or play the previous track using the left earbud in Mono (single earbud) mode.

WEEE INFORMATION




This device and any electrical accessories are compliant with local applicable rules on the restriction of the use of certain hazardous substances in electrical and electronic equipment

Disclaimer:
Features may vary by product model. For detailed specifications, please refer to the product user guide.
Due to ongoing improvements, specifications are subject to change without prior notice. We continuously enhance our products to ensure the highest quality.

QUICK GLANCE ON FUNCTIONALITIES

3 Times	Triple tap on left CTC to activate default smart voice assistant
3 Seconds	Long touch both CTCs for 3 seconds to manually power on, indicated by blue LED flash for 1 second
5 Seconds	Long touch both CTCs for 5 seconds to perform factory reset
8 Seconds	Long touch either CTC for 8 seconds to manually power off



LEARN MORE ABOUT YOUR PRODUCT



Scan this QR code to access your Product's Manual, FAQs and Warranty Information