AIRDOPES 311 PRO



boat

AIRDOPES 311 PRO

Thank you for choosing boAt Airdopes 311 Pro. This manual is your guiding map for navigating the shores of musical bliss. Knowledge of Bluetooth and device connectivity is essential for steering this boAt. So, we strongly recommend that this manual be read thoroughly before use and referred to in times of difficulty.



IWP™ TECHNOLOGY

 \star Delve into the song, movie, or podcast of your choice in no time with $\mathsf{IWP}^{\mathsf{w}}$ technology.

 Simply open the lid of the charging case and your Airdopes 311 Pro will power on automatically.

 To disconnect from the sound, place the earbuds back into the charging case in the correct orientation and close the lid. The earbuds automatically switch off (Smart Power Off) and enter charging mode.

Dive in and out of the sound on your terms with a flip of the lid!

ASAP[™] CHARGE

· Low battery levels will no longer slow down your audio relaxation.

 ASAP[®] Charge in these earbuds gives you a performance of up to 150 minutes after just 10 minutes of charging so that you never miss a beat.

Enjoy a quick playtime boost and game or stream without battery woes!

BEAST[™] MODE

 Experience smooth gaming with synchronized audio and visuals using Airdopes 311 Pro.

When BEAST[®] Mode is activated, these earbuds deliver up to 50 ms low latency which eliminates disruptive lag.

· Virtual frames matched with impactful audio elevate gaming every time.

Made for the Gamers - By Gamers, BEAST[®] Mode reduces the latency significantly and improves the overall gaming experience.

ENX™ TECHNOLOGY

 Our ENx[®] technology in the earbud mics cancels background sounds ensuring that only your voice is communicated over calls, devoid of noise.

 The ENx*-enabled mics in Airdopes 311 Pro analyze your surroundings and suppress unwanted sounds so that your voice is conveyed clearly in all possible atmospheres, retaining the audio quality for high clarity.

+You don't have to activate $\mathsf{ENx}^{\mathsf{w}}$ as the 2x mics are equipped with the same and activated by default.

Deliver your voice without interruptions everywhere – traffic, railway stations, airports, workspace, literally wherever you are!

CAUTIONARY WARNINGS

 Please do not dismantle the product as it can lead to a fire or electrical breakdown and completely damage the product. Maintenance or servicing of the earbuds must be done only through a qualified service provide/manufacturer.

· Please do not use any oily/volatile liquid to clean the earbuds.

· Please do not use the earbuds in extremely hot or cold temperatures.

 Any damage to the earbuds that is NOT a manufacturing issue will make the product's warranty null and void.

 Do not use the earbuds when it is unsafe to wear them, such as while driving, crossing the street, or any other activity where full awareness of your surroundings is required.

 To avoid damage to your hearing, make sure that the volume on your media device is at an appropriate level as continuous exposure to noise levels at or above 85 dB can gradually lead to a loss of hearing.

RECOMMENDATION

The earbuds may start at 100% volume level when first switched on. You can adjust the volume to your preferred level using the volume controls on your phone/media device.

