



LUNAR DISCOVERY PRO



USER MANUAL



LUNAR DISCOVERY PRO

Thank you for choosing the boAt Lunar Discovery Pro as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.




Package Contains:

- boAt Lunar Discovery Pro x1
- USB Magnetic Charging Cable x1
- User Manual and Warranty QR Card x1
- 5 + 1 Stickers

CHARGING THE WATCH


The smartwatch must be charged before initial use. It takes up to 1.5 hours to be fully charged. Connect and charge the watch with the image below as a reference.

Note: Use a standard 5V/2A charger only.



TURNING THE WATCH ON/OFF AND RESTART

- Power On/Off: Long-press the side button for 3–5 seconds to turn the watch on or off.
- Restart: While the watch is on, long-press the side button to view the restart option.



CONNECTING TO THE APP

1. Downloading the boAt Crest App on your Device

Easily download the boAt Crest App on your device using the QR card included in the package. The app is available on both:

- App Store (for iOS 14.0 and above)
- Google Play Store (for Android 7.0 and above)

OR

- Scan the QR code of the app provided here to download the app.



2. PAIRING YOUR SMARTWATCH WITH YOUR DEVICE

1. Open the Crest app on your device.
2. Ensure the phone's Bluetooth, Notifications and Location functionalities are turned on for the best experience.
3. Search and select the 'Lunar Discovery Pro' on the app's home screen. It will also be available under the Lunar series.
4. Scan the QR code displayed on the watch to pair it with the app. You can also find the QR code under 'System' or 'App QR'. Alternatively, select 'Pair with Bluetooth', search for available devices, and choose the smartwatch named LDISCOVERYPRO_XXXX.
5. As the binding process will begin, you will receive a prompt confirming "Pairing Successful". A pop-up may appear requesting access to your contacts. Tap "Authorise" for a seamless experience.
6. Make sure battery optimisation is disabled for the Crest app.



Note: To ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone..

SYNCING YOUR SMARTWATCH TO THE APP

Data Synchronization

- Open the Crest app on your phone.
- Make sure your Lunar Discovery Pro is connected to the app.
- Synchronisation will start automatically once you enter the app interface.

Note: Synchronise data at least once every day to avoid data loss in the watch.

NAVIGATING THROUGH THE FUNCTIONS

CROWN FUNCTIONALITY (POWER/UPPER SIDE BUTTON)

Short Press:

- Silent Incoming Calls: Short press the side button to silence the incoming calls.
- Main Menu: Open the main menu or navigate within apps and widgets.
- Back Navigation: Short press once to go back to the previous screen. Keep pressing to reach the home screen.

Long Press:

Long press the side button to Power off or Restart.

Rotate:

- a. To scroll through the main menu.
- b. Switch between the default watch faces from the home screen.



APPS

QR Tray

Use this feature to add and access QR codes like metro tickets, UPI payments, or membership passes.

Steps to add QR codes to the smartwatch:

- Open the boAt Crest App on your phone.
- Go to Settings > Watch Features > QR Tray.
- Tap Upload to add a QR code from your phone (supported formats: PNG, JPG, HEIC).
- Enter a name under "Name this QR code."
- Select a category: Payment, Movie, or Others.
- Tap Save & Push to Watch.

After this, you'll be able to find a collection of QR codes in the smartwatch under the QR Tray feature.




Note: Swipe left from the home screen to view the QR code on the watch.

SMART ALERTS

Tap here to check/receive smart alerts. Follow the steps mentioned below to enable the smart alerts from the supported apps:

1. Go to "Settings" on your Crest app.
2. Tap on "Notifications".
3. Enable the "App Notifications".
4. From the list, select the "Uber app" that supports Smart Alerts.
5. Make sure Notification Access is granted to the boAt Crest app in your device settings.

Once set, the user will start receiving quick updates like ride status etc.



CALL

- **Dialer:** You can use the dialler to dial any number.
- **Phone Book:** Add up to 20 contacts from the boAt Crest app. You can select any contact to directly dial from the contacts of the watch.
- **Call History:** You can find recently received, missed, and outgoing call logs in the Call History of the watch.



ACTIVITIES

The smartwatch comes equipped with multiple sports modes to help you track your workouts effectively.


1. Quick-Start an Activity with the Lower Side Button

Short press the lower side button to begin an activity. Choose from various default activities. You can choose from a variety of modes, including: Walking, Treadmill, Running, Badminton, Football, Basketball, Tennis, Yoga, Dancing, Cycling, and Indoor Cycling and more.

2. Launching an Activity via the Main Menu

- Short press the upper side button to open the main menu.
- Go to Activities.
- Select the Activity of your choice.
- Tap the Start button to begin tracking the activity duration.
- As your activity proceeds, swipe left to access music controls during your session.
- Once done, either pause or stop the activity manually.

Note: The activity will not be recorded if the total duration is less than 3 minutes.



ACTIVITY RECORDS

The smartwatch automatically stores data for your completed activities, including duration, distance and calories burned. Moreover, depending on the activity chosen, it also displays heart rate and other metrics relevant to the particular activity.

Quick Access Path on Smartwatch: Main Menu > Activity Records > Records

Check Detailed Activity Records on the Crest App:

- Open the Crest App on your device.
- Ensure your smartwatch is connected to the app.
- Sync your smartwatch data with the app to access complete activity records.
- Go to the Wellness > Movements > Activities section within the app to review past activities.



HEART RATE

Tap the heart rate icon to start monitoring. Wear the smartwatch on your wrist, then click on the "measure" to start the heart rate real-time measurements. The feature lets you monitor your –

- Current Beats Per Minute (BPM)
- Max BPM
- Min BPM
- Resting BPM

Users can also view the detailed data on the boAt Crest app.

Note: Measurements are for reference only and not for medical purposes.



SpO2

Tap on the SpO2 icon to check blood oxygen level. Wear the smartwatch on your wrist, then click on the "measure" to start the SpO2 real-time measurements. You can also access SpO2 data through the app.

Note: Measurements are for reference only and not for medical purposes.



SLEEP

Tap on the icon to review the sleep data of the previous night. Once the sleep criteria are met, your smartwatch records sleep between 8:00 PM and 10:00 AM. If you lie down and the watch detects no movement for 30 minutes, recording will begin. It stops automatically if excessive movement is detected. You can use this feature to monitor your –

- Deep sleep
- Light sleep
- REM
- Awake

Users can also view the detailed data on the boAt Crest app. Sleep data on the app is available only after the awake criteria are met.


Note: For accurate sleep data recording, the asleep criteria have to be met, which include limited movement, wrist positions and angles, and more. The awake criteria will be met only after it records some noticeable movement.



WELLNESS BALANCE

Wellness Balance is a daily score that offers a snapshot of your overall well-being, based on key lifestyle markers tracked by your smartwatch. A higher score reflects better balance across core wellness parameters such as activity, sleep, heart rate, and SpO2. It may help you monitor how your daily habits affect your health and identify areas for improvement.

Note: Wellness Balance tracking begins after 2 weeks of consistent activity. This score is meant to be used as a guidance tool for self-monitoring and not for any medical diagnosis or treatment. Use it to stay consistent and make healthier lifestyle choices over time.



FEMALE WELLNESS

Enable and set the details on the boAt Crest App to receive alerts for your period and ovulation dates directly on the watch.

Note: This feature is available only if 'Female' is selected as the gender during the initial watch and app setup.



BREATH EXERCISE

Tap on the Breath Exercise icon to begin a guided breathing session. You can set the duration from 1 minute to 3 minutes and choose the intensity level—Slow, Moderate, or Fast—as per your comfort.

Note: For best results, sit in a relaxed position and focus on your breath during the session.



CAMERA CONTROL

Tap on the remote camera icon on your smartwatch to click a photo from your phone.



MUSIC CONTROL

Tap on the Music Control icon on your watch to control music playback from your phone. You can perform the following actions:

- Play/Pause the track
- Skip to the Next or Previous track
- Adjust the Volume Up or Volume Down

Note: Ensure your watch is connected to your phone via Bluetooth. Some music apps with different control protocols may not be supported.



VOICE ASSISTANT

Tap on this to enable the voice assistant feature and give the command from the watch.

Note: Make sure the watch is connected to the boAt Crest App.



WEATHER

Connect your smartwatch to the boAt Crest App to receive real-time weather updates on your watch. You can view the following parameters:

- Temperature
- Humidity Levels
- Wind Speed
- Pressure

Note: Your smartwatch refreshes the weather information periodically. Ensure the watch stays connected to the app for accurate updates.



ALARM

Tap on this to set an alarm on your watch.



NOTIFICATIONS

You can check all the notifications from here.



REMINDERS

You can set any upcoming reminders from here.
To set a reminder:

- Open the boAt Crest App
- Go to Settings > Watch Features > Custom Reminders
- Tap on Set Reminder
- Enter your reminder details and save

The reminder will appear on your watch at the scheduled time.

Note: Make sure your watch is synced with the app to receive reminder notifications.



STOPWATCH

Click on this to start the stopwatch on your watch.



TIMER

Tap on the Timer icon to set a countdown timer on your watch. You can choose from the following preset durations: 1 min, 3 min, 5 min, 10 min, 15 min, 30 min, 1 hour, 2 hours, or set a Custom timer.

Note: The timer will continue running in the background even if you switch screens.



FLASHLIGHT

Tap the Flashlight icon to turn the watch screen bright white. This feature is useful in low-light situations like running, hiking, or emergencies.

Note: Press the side upper button to turn off the flashlight.



FIND PHONE

Tap on the Find Phone icon to locate your paired device. Once activated, your device will start ringing and vibrating. Short press the side button on the watch to stop the alert.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.



SETTINGS

WATCH FACES

Tap on this icon to change your watch face. You can choose from 4 default watch faces. Alternatively, you can long press the home screen or rotate the side button to switch between the watch faces.



SCREEN SLEEP

Tap on the Screen Sleep option to adjust the screen timeout duration. You can set it from 1 second to 20 seconds based on your preference.

Note: Longer screen time may lead to faster battery consumption.



RINGTONE

Manage your watch's sound preferences from the Ringtone settings.

- **Silent Mode:** Enable to mute all sound alerts.
- **Ringtone:** Choose between available options: Dream or Calm.
- **Ringtone Volume:** Adjust the volume level as per your preference.

Note: Ensure Silent Mode is turned off to hear ringtone alerts.



WAKE GESTURE

Enable the Wake Gesture to automatically turn on the screen when you raise your wrist. You can choose between:

- **All Day:** Keeps the gesture active throughout the day.
- **Schedule:** Set a specific time window during which the gesture is active. To set a schedule:
 - **Start Time:** Set start time (e.g., 08:00 AM)
 - **End Time:** Set end time (e.g., 10:00 PM)

Note: Keeping the Wake Gesture active all day may lead to faster battery drain.



VIBRATION

Tap on the vibration setting to adjust the vibration intensity of your smartwatch. You can choose from:

- Strong
- Soft
- None

Note: Selecting 'None' will disable all vibration alerts on your watch.



DO NOT DISTURB

Tap on the DND option to enable Do Not Disturb mode. You can choose between:

- **All Day:** Keeps DND active throughout the day.
- **Schedule:** Set a specific time window when DND will automatically turn on and off.

Note: While DND is enabled, all notifications and reminder alerts will be silenced.




BEDTIME MODE

Tap on Bedtime Mode to limit interruptions during your sleep hours. You can choose between:

- **All Day:** Keeps bedtime mode active throughout the day.
- **Schedule:** Set a custom time range when bedtime mode should be active:
 - a) Start Time: Set when bedtime mode begins (e.g., 11:00 PM)
 - b) End Time: Set when bedtime mode ends (e.g., 07:00 AM)

Note: Enabling Bedtime Mode will also activate DND, Silent Mode, and disable the Wake Gesture.



BATTERY SAVER MODE

Enable Battery Saver Mode to extend the battery life of your smartwatch.

- **Standard Mode:** Disables wake gesture and auto-monitoring features. Sets brightness to minimum, screen sleep to 5 seconds, and turns off watch vibrations.
- **Advanced Mode:** Includes all settings from Standard Mode, plus enables DND, silences all notifications except alarms, and turns off all watch vibrations.
- **Auto On:** Set a battery percentage between 10% and 70% to automatically activate battery saver mode.

Note: Activating battery saver may limit certain features and background functions



SYSTEM

Tap on this to restart, power off and factory reset the smartwatch.



DOWNLOAD APP

Tap on this and scan the QR code of the boAt Crest app.



ABOUT

Shows the device details.



SWIPE LEFT OR RIGHT TO ACCESS WIDGETS

Swipe left from the home screen to access features like Steps, Wellness Balance, Heart Rate, SpO2, Sleep, Well-Being, Weather, Music, QR Tray, Phone Book, and Notifications.

Alternatively, swipe right to return to the previous screen.



SWIPE UP TO ACCESS THE SPORTS SCORE

You can check live cricket and football scores directly on your smartwatch. To enable and view sports scores:



- Open the boAt Crest App on your device.
- Go to the My Watch section.
- Tap on Sports Score.
- Select Enable Now to activate live score updates.
- Turn on Enable Score Push to Watch for real-time updates.
- (Optional) Enable Vibration Alert to get notified when scores are updated.

Sports Score Settings:

- **Cricket:** Choose the match type – T20 or ODI – and set your preferred update interval.
- **Football:** Tap on Get Score Update to receive updates every 15 minutes.

Note: Only one sport can be selected at a time. Switching the sport will stop score updates for the previously selected one.

Enabling vibration alerts may lead to increased battery consumption.



SWIPE DOWN FOR THE SHORTCUT MENU

You can access DND, Settings, SOS, Call, Brightness, Battery Saver, Silent Mode, Wake Gesture, Always on Display, Bedtime, Find My Phone, and Off/Restart



EMERGENCY SOS WITH LOWER SIDE BUTTON

The Emergency SOS feature helps you instantly alert your emergency contact during a critical situation.

To activate Emergency SOS from your watch:


- Press and hold the lower side button on your watch for 5 seconds.
- An SOS call will be sent to your registered emergency contact.

Steps to set up an emergency SOS contact:

- Open the boAt Crest App on your device.
- Navigate to the Home Dashboard.
- Locate the Top Features section.
- Tap on SOS to access the Emergency SOS settings.
- You will be prompted to enable necessary permissions: Call, SMS, and Location.
- Select and register your emergency contact from your phonebook.

To initiate an SOS call:

- Press and hold the lower side button on your smartwatch for 5 seconds.



Note:

- You can only register 1 emergency contact with the boAt Crest app.
- The smartwatch must be connected to the App.

PRODUCT PARAMETERS

Model	Lunar Discovery Pro
Screen type	1.39" (3.53 cm) HD Display
Battery capacity	300 mAh
Net weight	20 g
Bluetooth version	Bluetooth 5.3
Charging time	1.5 Hour
Working time	7 days* (Battery life may vary depending on usage)
Water Resistance	IP67

Maintenance

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap-less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

Frequently Asked Questions (FAQs)

Search for the app to connect keeps failing.

1. *Keep the boAt Crest app updated to the latest version.*
2. *Close all the programs on the device → Stop and restart Bluetooth and GPS → Connect again.*
3. *Check and enable the notification functions of your phone and keep the phone and watch in close contact.*

Note: Make sure your phone system meets Android 7.0 and above and iOS 14.0 and above.

My smartwatch is not receiving alerts, texts, or phone calls.

Make sure that smart reminders are enabled and synced with the watch via the boAt Crest App.

Also, make sure the notification centre of the phone is displaying messages. Only then will your smartwatch also display those notifications.

Make sure the app is running in the background and the battery optimisation feature on the phone is disabled.

My Bluetooth keeps getting disconnected.

- Make sure there is not more than a 10m distance between the Bluetooth on the phone and the watch.
- There is no obstacle between the watch and the phone.
- Make sure the app is running in the background.

Which functions of Lunar Discovery Pro need Bluetooth to work?

Bluetooth must be continuously enabled on both devices for these features to function reliably. Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, and Bluetooth calling require the proper Bluetooth connectivity to work.

Will it be okay to take a bath wearing Lunar Discovery Pro?

The IP67 water resistance will only work under the following conditions:

(1) Maximum depth of water: 1.5 m

(2) Maximum time for exposure to water: 10 minutes

The watch isn't suitable for hot baths, hot springs, saunas, snorkelling, diving, water skiing and other wading or deep-water activities with high-speed water flow

SAFETY & PRODUCT INFORMATION

Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate data is for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tightly. Make sure you keep your skin dry - the area that comes in contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

Things to keep in mind

- Sync data everyday days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents & other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is for free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort you contribute to recycle valuable raw materials and treatment of toxic substances.

